

Creaking noises at driver's seat when cornering

Topic number	LI91.10-P-066971
Version	2
Function group	91.10 Front seats
Date	09-05-2017
Validity	W/S205 X/C253 Seat belt buckle creaks on front seat
Reason for change	Part number of felt has changed and a template has been added.
Reason for block	

Complaint:

Creaking noises at driver's seat when cornering

Cause:

Creaking noises can occur at the front seat cover due to the material pairing between the seat belt buckle and the seat cover.

Remedy:

Check whether the seat belt buckle is resting on the seat cover and whether this is causing the noise. If so, line the seat belt buckles on both front seats with felt according to the template (Pic.1).

Important: The label (Pic.2, area shaded in black) on the seat belt buckle must not be lined with felt. It is not necessary to remove the seat belt buckles.

Only the felt with the part number A000 983 89 10 may be used. Any other felt will not provide a lasting remedy.

IT IS NOT NECESSARY TO REPLACE THE SEAT BELT BUCKLES!

Attachments	
File	Description
Pic.1.JPG	Template with dimensions A: 25 mm B: 65 mm C: 20 mm
Pic.2.jpg	Drawing of position of felt

Symptoms
Body / Seat / Noises / Cracking
Body / Seat / Noises / Creaking
Body / Safety system / Seat belt / Seat belt / Noise

Parts						
Part number	ES1	ES2	Designation	Quantity	Note	EPC
A 000 983 89 10			Felt	1	70x3x10000 mm	X


XENTRY TIPS

Operation numbers/damage codes				
Op. no.	Operation text	Time	Damage code	Note
			91A53 36	Felt on left front seat belt buckle
			91N53 36	Felt on right front seat belt buckle

Attachments

XENTRY TIPS

Pic.1.JPG:



XENTRY TIPS

Pic.2.jpg:

